Comment installer la base pivotante


Step 1

Installation of cross rail

a) Align points A & B of the cross rail to the corresponding points of the mechanism (raised side towards the furniture).

b) Insert the four ¾" self-tapping
(figure 1) screws and screw them with a 7/16 " key or wrench.

Install two legs (figure 2) screwable on the back of the chair



View from underneath the furniture




figure 1



el ran

How to install the Swivel Base-next page

Step 2

Installation of the swivel base


(It is preferable to start by the front of the chair.)


a) Align number 1 & 2 of the swivel base to the corresponding numbers of the mechanism.



- b) (Front of the chair) Place the 2 plastic spacers , one on each side, in between the swivel base and the mechanism in position 1 & 2.
- c) Insert two 2" bolts in the holes and place the lock washers, followed by the 1/4" nuts under the bar.
- d) (Back of the chair) Align number 3 & 4 of the swivel base to the corresponding numbers of the mechanism.
- e) Insert two 1 1/4" bolts in the holes and place the lock washers, followed by the 1/4" nuts under the bar.
- f) Screw the 4 bolts tightly with a 7/16" key or a wrench.

Back of the chair





Front of the chair



How to install the Swivel Base-next page

Install the screwable legs (figure 2) at the back of the chair only (step 1). Note: Tools required (not included): 7/16" key or a wrench.

figure 2



#1 & 2 = Front of the chair

