


User guide for lift recliners (1 motor)

1-Tip the chair towards the front.




2-Take the bag that contains the connecting items which you will find inside the back behind the furniture.



Contained in plastic bag

Plug according to the following drawings.



A & B: Plug the wires to the transformer and under the base.

Using the 1 motor system



Lift chair
and/or
close back and footrest.

Lower chair
and/or
Recline back and open
footrest .

For your safety

- *Do not try to close the footrest if someone or something is under it.
- *Do not try to get out of the recliner if the footrest is open.
- *Do not let children use the recliner without supervision.
- *Unplug the transformer when the furniture is not in use.